
OHC 100 SERIES

FALCON®

Models: 090, 090H, 105, 105H POWER ADJUSTABLE

CONCEALED OVERHEAD DOOR CLOSER INSTALLATION INSTRUCTIONS

FOR 105° OR 90° DOOR OPENING WITH OR WITHOUT HOLD OPEN
CENTER HUNG, DOUBLE OR SINGLE ACTION DOORS
SIDE LOADING, END LOADING AND OFFSET SLIDE ARM INSTALLATION
SEPARATE VALVES FOR MAIN AND LATCH SPEED ADJUSTMENT




IMPORTANT

To prevent damage to door closer, do not drill into DOOR HEADER after installing closer.

PROPOSAL for DOOR CLEARANCE

both of the door stiles 1/8" (3mm) top door rail 1/8" (3mm) bottom door rail 3/16" (5mm)

SPEED ADJUSTMENT





Speed adjustment Max. 2 turns in either direction.

POWER ADJUSTMENT

General Notes:

- 1. Offset kits do not include butt hinges, pivots or arm covers.
- Cover plate to be provided by frame manufacturer.

Use 3/16" allen wrench provided to adjust.


OHC 101 (Size 1-3)		
Size	Number of Turns	Direction
1	-4	Counter Clockwise
2	0	Factory Setting
3	+4	Clockwise

OHC 100 (Size 3-5)		
Size	Number of Turns	Direction
3	-4	Counter Clockwise
4	0	Factory Setting
5	+4	Clockwise






1. Prepare jamb and header for closer installation, as shown.




Drill holes in jamb for #10 pan head self-threading screws.



* This dimension may vary for some offset slide arm applications. See offset slide arm installation instruction sheets. Drill and counter-sink outside top surface of header, as shown.

Cover Plate Template

(Cover plate & fasteners to be provided by frame manufacturer.)



** This dimension may vary for some offset slide arm applications. See dimension "A" in charts located within offset arm instructions.

