

Rim Exit Device



Installation Instructions

Devices covered by these instructions:

XP98/XP99 Rim Exit Device HH/HW XP98/XP99 Hurricane Rated Exit Device XP98-F/XP99-F (Fire) Rim Exit Device HH/HW XP98-F/XP99-F Hurricane Rated (Fire) Exit Device CDXP98/CDXP99 (Cylinder Dogging) Rim Exit Device

<u> </u>		
Γ	Special tools needed:	

Taps: #10-24, 1/4"-20

Drill bits: #7, #25, 1/8", 1/4", 5/16", 3/8", 13/32"

Index:• Screw chart2• Preparation chart3• Device installation4-6• Retrofit installation7• Hex dogging information8• CD (cylinder dogging)9• Cut device10• 954 strike installation10

Please give these instructions to building owner after device is installed

HURRICANE RATED DEVICE REQUIREMENTS


Hurricane rated exit device requirements (when used with approved Allegion door applications)

Through Bolts	 When installing a Wind and Impact-rated hurricane device (HH), through bolts must be used. Through bolts are noted throughout the instructions where applicable. If through-bolting trims are used, these trims are equivalent in function and are used in place of through bolts. 				
Application		Single door standard strike	Mullion	Double door standard strike	
HH (Wind and	XP98/XP99	909	HH9954	909	
Impact rated)	XP98-F/XP99-F			954	
	y) XP98/XP99	909	4954XP or KR4954XP	909	
HW (Wind Only)			5654XP		
	XP98-F/XP99-F	909	9954XP or KR9954XP	954	

	SCREW CHART	
909 Strike	1/4"-20 X 3/4" (3 qty)	
954 Strike	1/4"-20 X 3/4" (6 qty)	
C	Image: Constraint of the second se	Through bolts (1-3/4" door) — Through bolts (2-1/4" door) — Surface mount (wood) — 990 Trims (1-3/4" door)
	Image: Contract of the second seco	
9	() 1111155 #10-16 X 3/8" Thread cutting (2 qty)	- End cap screw
	#10-24 X 1" (2 qty) #10 X 1-1/4" Wood screw (2 qty)	
	#8-18 X 3/8" Thread cutting (4 qty)	- Cover screw


PREPARATION CHART

Go to "Device Installation" on next page before using this preparation chart



DEVICE INSTALLATION

Note: For retrofit applications where an existing 98/99 Rim device is being replaced, see "Retrofit Installation" on page 7.




Center

case

cover


Prepare lock side of door for device and trim.




Trim


(optional)

С






 A. With door closed, push against door without touching device.
 Device should NOT allow door to open.




B. With door closed, push device pushbar. Device should allow door to open.



C. If device does not function as described, adjust strike position and continue operational check until device functions as described above.




When properly adjusted, secure strike with additional screw(s).






Note about the XP latch operation

The XP latch bolt operates differently from a standard latch bolt. When the pushbar is depressed, the latch bolt does not retract. This is normal because the XP latch bolt can swivel in both directions.



RETROFIT INSTALLATION



If plastic template will not align correctly with the 4 outer holes, bolt new XP exit device on door temporarily with the 4 screws and use it as a template to mark the 2 holes shown above.


device installation steps 7-10.

HEX DOGGING INFORMATION

To undog exit device:

Note: Panic devices are shipped dogged (pushbar down).


1. To undog device, place hex key in hole as shown and turn counterclockwise releasing pushbar.



To dog exit device:


Note: Dogging is recommended during times of high traffic through door.

- 1. Depress pushbar.
- 2. Place hex key in hole as shown and turn clockwise. Pushbar stays in down position.




CD (CYLINDER DOGGING)

(DO NOT USE ON FIRE RATED DEVICE)



CUT DEVICE



This page left intentionally blank

This page left intentionally blank



