

INTERIOR OR EXTERIOR MTK15 TO SIGNAL FSE eSTRIKE TO RELEASE THROUGH SES CT5000.

FIRE ALARM TO DISABLE MTK15 FUNCTION AND CAUSE FSE STRIKE TO REMAIN LOCKED. IN THIS DIAGRAM THERE WILL BE NO PASSAGE THROUGH THIS OPENING UNDER A FIRE ALARM CONDITION.

IF FIRE ALARM IS NOT REQUIRED OMIT FA BOARD IN PS902-FA POWER SUPPLY.

SET PS902 VOLTAGE TO 12VDC.

CREATOR: BRENDA DOVE 02/20/12	TITLE: CT5000/MTK15 with KEYPAD and FSE eSTRIKE	222124CT5000 Rev 2
APPROVED: TODD GINTER 02/29/12		10/11/12 revision 2