



INSTALLATION INSTRUCTIONS

1. PREPARE INSIDE FACE OF DOOR FOR DEVICE.
 - A. SEE DEVICE DIRECTIONS FOR LOCATIONS OF VERT. AND DEVICE REF. CENTERLINES.
2. PREPARE OUTSIDE FACE OF DOOR FOR TRIM.
 - A. TRANSFER VERT. AND DEVICE REF. CENTERLINES FROM INSIDE FACE TO OUTSIDE FACE OF DOOR. BE SURE VERT. CENTERLINE IS PARALLEL TO EDGE OF DOOR.
 - B. LOCATE AND PREPARE ALL HOLES AS INDICATED.
3. INSTALL CYLINDER (IF REQUIRED).
 - A. IF USING MORTISE CYLINDER, INSTALL CYLINDER INTO MORTISE LOCK.
 - B. IF USING RIM CYLINDER, INSTALL CYLINDER USING CYLINDER ROSE. THEN CUT TAILPIECE TO EXTEND 3/8" BEYOND INSIDE FACE OF DOOR.
4. INSTALL TRIM ON DOOR AND CUT THUMBPIECE TO SIZE.
 - A. TRIM MOUNTING.
 - TOP OF PULL: 1/4"-20x2" FPHMS
 - BOTTOM OF PULL: 1/4"-20x2-1/4" FPHMS FINISH WASHER
 - B. CUT THUMBPIECE:
 - RIM & VERTICAL: THUMBPIECE TO EXTEND 5/8"-3/4" BEYOND DOOR SKIN.
 - MORTISE: THUMBPIECE TO BE INSIDE DOOR SKIN BY 1/4".
5. INSTALL DEVICE ON DOOR PER DEVICE INSTRUCTIONS.

DEVICE	"A"	"B"	DEVICE	"A"	"B"
(F)XX-R-T	OMIT	1-1/4"	(F)18-R-T (LS/LK)	OMIT	OMIT
(F)XX-R-T (LS/LK)	OMIT	OMIT	(F)18-R-T (NL)	OMIT	1-1/4"
(F)XX-R-T (NL)	OMIT	1-1/4"	(F)18-R-T2	1-1/4"	OMIT
(F)XX-R-T2	1-1/4"	OMIT	(F)18-R-T (2O.C.)	1-1/4"	1-1/4"
(F)XX-R-T (2O.C.)	1-1/4"	1-1/4"	(F)18-M-T	1-1/4"	OMIT
(F)XX-M-T	1-1/4"	OMIT	(F)18-M-T (LS/LK)	OMIT	OMIT
(F)XX-M-T (LS/LK)	OMIT	OMIT	(F)18-M-T (NL)	1-1/4"	OMIT
(F)XX-M-T (NL)	1-1/4"	OMIT	(F)18-M-T2	1-1/4"	OMIT
(F)XX-M-T2	1-1/4"	OMIT	(F)18-V-T	1-1/4"	OMIT
(F)XX-V-T	1-1/4"	OMIT	(F)18-V-T (LS/LK)	OMIT	OMIT
(F)XX-V-T (LS/LK)	OMIT	OMIT	(F)18-V-T (NL)	1-1/4"	OMIT
(F)XX-V-T (NL)	1-1/4"	OMIT	(F)18-V-T2	OMIT	1-1/4"
(F)18-R-T	OMIT	1-1/4"	(F)18-V-T (2O.C.)	1-1/4"	1-1/4"

CORRESPONDS TO TEMPLATES T-2093 AND W-2093

MONARCH
Exit Devices & Door Hardware

TECHNICAL SERVICE / CUSTOMER SERVICE 800-826-5972
FAX-ON-DEMAND 877-454-9696

TITLE: **ZEPHYR TRIM - T FUNCTIONS
(F)18 & (F)XX SERIES DEVICES**

FOR ZEPHYR TRIM - DT & P FUNCTION, SEE OTHER SIDE

DATE: 3-1-98
DIRECTION SHEET - REV.
D-2093-2