

INSTALLATION INSTRUCTIONS TO POSITION TAILPIECES

WOOD CHIPS AND SAWDUST SHOULD BE REMOVED FROM HOLES BEFORE LOCK IS INSTALLED

1. ROTATE TAILPIECE OF OUTSIDE CYLINDER ASSEMBLY TO POSITION TAILPIECE JOG AS INDICATED, AND INSERT THROUGH LATCH HUB.
2. INSTALL INSIDE CYLINDER ASSEMBLY SAME AS STEP #1. TAILPIECE WILL REST ON TOP OF OUTER TRIM TAILPIECE.

3. CAUTION:
TAILPIECE JOGS MUST BE POSITIONED AS SHOWN FOR PROPER ALIGNMENT AND FUNCTION OF LOCK.

