



LHR SHOWN
RHR OPPOSITE

INSTALLATION INSTRUCTIONS

1. PREPARE INSIDE FACE OF DOOR FOR DEVICE.
 - A. SEE DEVICE DIRECTIONS FOR LOCATIONS OF VERT. AND DEVICE REF. CENTERLINES.
 2. PREPARE OUTSIDE FACE OF DOOR FOR TRIM.
 - A. TRANSFER VERT. AND DEVICE REF. CENTERLINES FROM INSIDE FACE TO OUTSIDE FACE OF DOOR. BE SURE VERT. CENTERLINE IS PARALLEL TO EDGE OF DOOR.
 - B. LOCATE AND PREPARE ALL HOLES AS INDICATED.
 3. INSTALL TRIM ON DOOR AND CUT LEVER SPINDLE TO SIZE.
 - A. TRIM MOUNTING.
 - FOUR STUDS: ARE THRU-BOLTED TO DEVICE WHEN DEVICE IS INSTALLED.
- NOTE: FOR F-18-R & F-XX-R DEVICES, INSERT SEXBOLTS INTO TWO HOLES PRIOR TO INSTALLING TRIM.**
- B. CUT LEVER SPINDLE: LEVER SPINDLE TO EXTEND 5/8"-3/4" BEYOND DOOR SKIN.
4. INSTALL CYLINDER (IF REQUIRED). INSTALL RIM CYLINDER AND CUT TAILPIECE TO EXTEND 3/8" BEYOND INSIDE FACE OF DOOR.
 5. INSTALL DEVICE ON DOOR PER DEVICE INSTRUCTIONS.

DEVICE	"A"	"B"	DEVICE	"A"	"B"
(F)XX-R-LE	OMIT	1-1/4"	(F)18-R-LE	OMIT	1-1/4"
(F)XX-R-LE (LS/LK)	OMIT	OMIT	(F)18-R-LE (LS/LK)	OMIT	OMIT
(F)XX-R-LE (NL)	OMIT	1-1/4"	(F)18-R-LE (NL)	OMIT	1-1/4"
(F)XX-R-LE DT	OMIT	OMIT	(F)18-R-LE DT	OMIT	OMIT
(F)XX-R-P x LE DT	1-1/4"	OMIT	(F)18-R-P x LE DT	1-1/4"	OMIT
(F)XX-R-LE2	1-1/4"	OMIT	(F)18-R-LE2	1-1/4"	OMIT
(F)XX-R-LE(2O.C.)	1-1/4"	1-1/4"	(F)18-R-LE(2O.C.)	1-1/4"	1-1/4"

NOTE: DIMENSIONS "A" & "B" ARE THE SAME FOR LE & SE TRIM REGARDLESS OF TRIM FUNCTION

CORRESPONDS TO TEMPLATES T-2099 AND W-2099

MONARCH
Exit Devices & Door Hardware

TECHNICAL SERVICE / CUSTOMER SERVICE 800-826-5972
FAX-ON-DEMAND 877-454-9696

TITLE: **LE & SE TRIMS FOR (F)18 & (F)XX SERIES RIM DEVICES**

FOR LE & SE TRIM FOR (F)18 & (F)XX VERTICAL, MORTISE & THREE POINT LATCH DEVICES, SEE OTHER SIDE

DATE: 3-1-98

DIRECTION SHEET - REV.

D-2099-2