



Total Door Undersizing

Single Square Edge Door - 15/32"
 Single Bevel Edge Door - 1/2"
 Pair of Doors, each leaf, Square Edge Door - 7/16"
 Pair of Doors, each leaf, Bevel Edge Door - 15/32"

See installation instructions for reinforcement requirements.

Hole Preparation

Metal Frame:

#12-24 x 3/4" self-drilling tapping screws
 #16 pilot drill is recommended for all holes

Wood Frame:

1/8" pilot drill

Vertical distance between holes

	A	B	C	D
Inch	1.50"	2.50"	3"	10"
mm	38.1	63.5	76.2	254.0

IVES

114XY 95" FULL MORTISE, CONCEALED
 NARROW FRAME WITH EDGE PROTECTOR
 CONTINUOUS HINGE TEMPLATE

ALLEGION

NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE
 NUMBER: 829705(B)

Date:
 10-16-15