



**Total Door Undersizing**

Single Square Edge Door - 15/32"  
 Single Bevel Edge Door - 1/2"  
 Pair of Doors, each leaf, Square Edge Door - 7/16"  
 Pair of Doors, each leaf, Bevel Edge Door - 15/32"

See installation instructions for reinforcement requirements.

**Hole Preparation**

**Metal Frame:**  
 #12-24 x 3/4" self-drilling tapping screws  
 #16 pilot drill is recommended for all holes

**Wood Frame:**  
 1/8" pilot drill

**Vertical distance between holes**

	A	B	C	D
Inch	1.50"	2.50"	3"	10"
mm	38.1	63.5	76.2	254.0