



Total Door Undersizing

- Single Square Edge Door - 11/32"
- Single Bevel Edge Door - 5/16"
- Pair of Doors, each leaf, Square Edge Door - 9/32"
- Pair of Doors, each leaf, Bevel Edge Door - 5/16"

See installation instructions for reinforcement requirements.

Hole Preparation

Metal Frame:
#12-24 x 3/4" self-drilling tapping screws
#16 pilot drill is recommended for all holes

Wood Frame:
1/8" pilot drill

Vertical distance between holes

	A	B	C	D	E	F	G
Inch	1.50"	2.50"	3.00"	3.50"	5.00"	5.50"	10.00"
mm	38.1	63.5	76.2	88.9	127	139.7	254

IVES

053XY 119" HALF SURFACE
NARROW FRAME AND DOOR STILE
CONTINUOUS HINGE TEMPLATE

ALLEGION

NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE
NUMBER: 829733(C)

Date:
1-23-18