



Total Door Undersizing

- Single Square Edge Door - 15/32"
- Single Bevel Edge Door - 1/2"
- Pair of Doors, each leaf, Square Edge Door - 7/16"
- Pair of Doors, each leaf, Bevel Edge Door - 15/32"

See installation instructions for reinforcement requirements.

Hole Preparation

- Metal Frame:**
 #12-24 x 3/4" self-drilling tapping screws
 #16 pilot drill is recommended for all holes
- Wood Frame:**
 1/8" pilot drill

Vertical distance between holes

	A	B	C	D	E	F	G	H
Inch	1.00"	1.50"	2.00"	2.50"	3.00"	5.00"	5.50"	10.0"
mm	25.4	38.1	50.8	63.5	76.2	127	139.7	254

IVES	045XY 83" & 85" HALF SURFACE NARROW FRAME CONTINUOUS HINGE TEMPLATE		
NOTE: DIMENSIONS IN () ARE IN MILLIMETERS		TEMPLATE NUMBER: 829725(A)	Date: 5-20-15