



### Total Door Undersizing

Single Square Edge Door - 11/32"  
Single Bevel Edge Door - 5/16"  
Pair of Doors, each leaf, Square Edge Door - 9/32"  
Pair of Doors, each leaf, Bevel Edge Door - 5/16"

See installation instructions for reinforcement requirements.

### Hole Preparation

**Metal Frame:**  
#12-24 x 3/4" self-drilling tapping screws  
#16 pilot drill is recommended for all holes

**Wood Frame:**  
1/8" pilot drill

### Vertical distance between holes

	A	B	C	D	E	F
<b>Inch</b>	1.50"	2.50"	3.00"	5.00"	5.50"	10.00"
<b>mm</b>	38.1	63.5	76.2	127	139.7	254

**IVES**

053XY 95" HALF SURFACE  
NARROW FRAME AND DOOR STILE  
CONTINUOUS HINGE TEMPLATE

  
**ALLEGION**

NOTE: DIMENSIONS IN ( ) ARE IN MILLIMETERS

TEMPLATE  
NUMBER: 829732(C)

Date:  
1-23-18