



INSTRUCTIONS:

1. PLACE DOOR IN POSITION AT POINT WHERE IT IS TO BE HELD OPEN TO OVERCOME DIFFICULTY OF UNEVEN FLOORS.
2. PLACE HOLDER IN POSITION AS SHOWN WITH RUBBER SHOE OF HOLDER RESTING FLAT ON THE FLOOR APPROXIMATELY 8" (203) FROM EDGE OF DOOR (SEE NOTE 1).
3. WITH HOLDER IN THE PROPER POSITION, MARK SCREW LOCATIONS. DRILL FOR APPROPRIATE SCREWS AND INSTALL SCREWS.

NOTES:

1. IF DOOR PIVOTS ARE WORN OR HAVE EXCESS PLAY, INSTALL HOLDER SO THAT THE RUBBER SHOE RESTS SLIGHTLY ON HEEL.
2. DOORS SHOULD BE PROPERLY REINFORCED WITH 3/16" (5) MINIMUM THICKNESS PLATE.

QTY.	SCREW DETAILS
3	#8 X 1" OPHSMS



**FS455 KICK DOWN HOLDER
INSTALLATION TEMPLATE**



NOTE: DIMENSIONS IN () ARE MILLIMETERS.

TEMPLATE NUMBER: INST.FS455_0

DATE: 09/01/01