



IN FRAME
2 HOLES
EACH STRIKE

DOUBLE DOOR APPLICATION SHOWN.
FOR SINGLE DOOR APPLICATION USE
APPROPRIATE HANDING AS SHOWN.

DEVICE APPLICATION SCHEDULE	
33/3547 & 33/3547-F SERIES DEVICE	
98/99/47 & 98/99/47-F SERIES DEVICE	
5547/5547 WDC SERIES	
33/3547A & 33/3547A-F SERIES DEVICE	
94/9547 SERIES DEVICE	
7547 & 7547-F SERIES DEVICE	
7847 & 7847-F SERIES DEVICE	

NOTES: 1. SEE DEVICE TEMPLATE FOR LOCATION OF LATCH BOLT.

2. IF DEVICE IS TO BE MOUNTED ON WOOD DOORS, SEE WOOD DOOR TEMPLATE FOR LATCH BOLT LOCATION.

338 Strike for Hollow Metal Frame Preparation

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE
NUMBER:

30038_b

DATE:
04-10-24