

55DU/RX55DU

VON DUPRIN

24509507

Dummy Crossbars

1 Prepare Door.


- a. Draw horizontal center line 3913/16" from finished floor.
- Tape full size Template 1 or 2, depending on handing of door, to inside face of lock stile and hinge stile. In addition to the templates, refer to Figure 1 (for single door) and Figure 2 (for a pair of doors) for placement of vertical center lines.
 - NOTE: Be sure center lines for lock/hinge stile cases are parallel to stop or edge of door.
- Prepare door as shown. See Figure 3 for metal door application, and Figure 4 for wood door application.


2 Apply Lock Stile Case.

a. Attach lock stile case to door (See Figure 3 or Figure 4).


Apply Hinge Stile Case and Crossbar Tube (Figure 5).


- Slip crossbar tube on lock stile and hinge stile lever arms. (See instruction 941009 for cutting crossbar, if necessary.)
- Be sure crossbar is level and hinge stile case is parallel to edge of door and approximately on center line of exposed stile.
- c. Using holes in hinge stile case, mark location and prepare door for sex bolts.
- d. Apply hinge stile case with crossbar in place.
- Tighten wedge-tite set screws securely with dog key and screwdriver or equivalent for leverage and test crossbar for free action. (See instruction 941009.)






Installation Instructions









Customer Service
1-877-671-7011 www.allegion.com/us

© Allegion 2014 Printed in U.S.A.

