

## 24 Series Exit Device Template Index Wood Door Applications

24 Series Device	Device Template
24-R, F-24-R	<a href="#">W-1320</a>
24-V, F-24-V, 24-V-LBR, F-24-V-LBR	<a href="#">W-1328</a>
F-24-C and F-24-C-LBR with Metal Edge 5" Stile	<a href="#">W-1342</a>
F-24-C 90 Minute and F-24-C-LBR 20 Minute, Full Steel Channel Stile Construction	<a href="#">W-1352</a>
24-C 20 Minute, Centerslide Preparation	<a href="#">W-1380</a>
24-C 20 Minute, Top Latch Preparation	<a href="#">W-1382</a>
24-C 20 Minute, Bottom Bolt Preparation	<a href="#">W-1383</a>

24 Series Device	700 Series Trim	Trim Template
24-R, F-24-R, 24-V-LBR, F-24-V-LBR	715DT	<a href="#">W-2320</a>
	711K, 711K-BE, 711K-NL, 712L, 712L-BE, 712L-DT, 712L-NL	<a href="#">W-2360</a>
	718C, 718DT, 718NL	<a href="#">W-2361</a>
	710TP, 710TP-BE, 718TP, 718TP-BE	<a href="#">W-2325</a>
24-V-LBR, F-24-V-LBR	719TL, 719TL-BE	<a href="#">W-2323</a>
24-C, F-24-C	717DT, 718C, 718DT, 718NL	<a href="#">W-2362</a>
	711K, 711K-BE, 711K-NL, 712L, 712L-BE, 712L-DT, 712L-NL	<a href="#">W-2363</a>

24 Series Device	24 Series Strike	Strike Template
24-R, F-24-R	299, 299F (standard)	<a href="#">W-3201</a>
	499F (optional with mullion)	<a href="#">W-3202</a>
	264 (optional)	<a href="#">W-3203</a>
	1439 (optional)	<a href="#">W-3204</a>
	1606 (optional)	<a href="#">W-3205</a>
24-V, F-24-V, 24-V-LBR, F-24-V-LBR	3788 Top Strike with 4215 angle bracket (standard)	<a href="#">W-3032*</a>
24-C, F-24-C, 24-C-LBR, F-24 -C-LBR	4188 Top Strike (standard)	<a href="#">W-3034*</a>
24-V, F-24-V, 24-C, F-24-C	2130 Bottom Strike (standard)	<a href="#">W-3053</a>
24-V, F-24-V, 24-C	2126-A Bottom Strike (optional)	<a href="#">W-3050</a>
	4155 Bottom Strike (optional)	<a href="#">W-3055</a>

\* For F-24-V-LBR and F-24-C-LBR applications add template [W-5494](#) for Auxiliary Fire Latch.