



Hole Preparation

3/8" Drill thru:
10 places

Metal frame:
Standard self drilling self tapping screws - No drilling required
Optional thread forming screws - #13 or 3/16" drill

Wood frame:
5/32" drill, 1.5" deep
14 places

Optional:
#12 Pan head, self drilling screws, 4 places

Vertical distance between holes		
	Inch	mm
A	1.5"	38.1
B	3"	76.2
C	2.5"	63.5
D	10"	254
E	5"	127

Notes
<p><u>Note: Total Door Undersizing</u> Single Square Edge Door - 7/32" Single Bevel Edge Door - 1/4" Pair of Doors, each leaf, Square Edge Door - 3/16" Pair of Doors, each leaf, Bevel Edge Door - 7/32"</p> <p>Reinforcement recommended for four hole pattern at top and bottom of each leaf of hinge.</p>



210HD 95" Surface Continuous Hinge Profile Template



© 2015 Allegion
829229-00
Rev. 01/15-c

Note: Dimensions in [] are millimeters

Template Number **829229-00(C)**