



**INSTRUCTIONS:**

1. PLACE HOLDER ON WALL AND LOCATE THE MOUNTING HOLES.
2. PREPARE MOUNTING HOLES.
3. INSTALL HOLDER.

QTY	SCREW DETAIL
2	#10 X 3/4 OPHSMS



**WS65 WALL BUMPER  
INSTALLATION INSTRUCTIONS**



NOTE: DIMENSIONS IN ( ) ARE IN MILLIMETERS

TEMPLATE  
NUMBER:

**INST.WS65\_B**

DATE:  
**05-29-15**