

941098-00


Control

371-L & 371-L-BE

VON DUPRIN

Installation Instructions

- Prepare door for exit device. Seexit device instructions for locations of holes, backset (line X-X), and center lines
- 2. Prepare door for control:
 - A. Transfer line X-X from inside (exit device side) of door to outside (control side) of door. Use extra care if edge of door is beveled. Be sure line X-X is parallel to edge of door.
 - **B.** Locate and prepare holes as indicated.
- 3. Install rod member (Figure 1):
 - A. Slip top rod assembly in door until bottom of rod is visible in control cutout.
 - B. Slip rod member on top rod according to handing of door. Keep rod member visible in cutout and lower top rod assembly until latch release is in position on latch release reinforcement. Slightly tighten socket set screws in rod member to maintain this position.
 - C. Complete the installation and adjustment of top and bottom rod assemblies. See directions for vertical rod device.
- 4. Install cylinder if required (Figs. 2 &3). Insure cylinder cam is set for required function and replace if necessary.
- Install control and adjust member so that the bottom surface is against top surface of control cam. Secure rod member by tightening socket set screws.
- Apply device and test key, control, and device action.



For cutouts on inside face of door see instructions in device carton	Device Application Schedule
	8847-F Vertical Rod Exit Device

Customer Service

1-877-671-7011

www.allegion.com/us



© Allegion 2014 Printed in U.S.A. 941098-00 Rev. 01/14-b

