

## **Knob Booster**

## **VON DUPRIN**®

941271-00 Replacement Kit

Installation Instructions

- 1. Knock out pin to remove old booster assembly.
- 2. Assemble booster body, spring, and spacer as shown in Figure 1.
- 3. Slide booster assembly on knob spindle.
- 4. Insert roll pin through spindle and booster body groove.

PUSH TABS TOGETHER-TO POSITION SHOWN BEFORE ASSEMBLY SPACER **BOOSTER BODY** SPRING ROLL PIN

For cutouts on inside face of door, see exit device instructions

**Customer Service** 

1-877-671-7011

www.allegion.com/us



© Allegion 2014 Printed in U.S.A. 941271-00 Rev. 01/14-b