



**LHR SHOWN**  
**RHR OPPOSITE**

**INSTALLATION INSTRUCTIONS**

1. PREPARE INSIDE FACE OF DOOR FOR DEVICE.
  - A. SEE DEVICE DIRECTIONS FOR LOCATIONS OF VERT. AND DEVICE REF. CENTERLINES.
2. PREPARE OUTSIDE FACE OF DOOR FOR TRIM.
  - A. TRANSFER VERT. AND DEVICE REF. CENTERLINES FROM INSIDE FACE TO OUTSIDE FACE OF DOOR. BE SURE VERT. CENTERLINE IS PARALLEL TO EDGE OF DOOR.
  - B. LOCATE AND PREPARE ALL HOLES AS INDICATED.
3. INSTALL CYLINDER (IF REQUIRED).
  - A. IF USING MORTISE CYLINDER, INSTALL CYLINDER INTO MORTISE LOCK.
  - B. IF USING RIM CYLINDER, INSTALL CYLINDER USING CYLINDER ROSE. THEN CUT TAILPIECE TO EXTEND 3/8" BEYOND INSIDE FACE OF DOOR.
4. INSTALL TRIM ON DOOR.
  - TOP OF PULL: 1/4"-20x2" FPHMS
  - BOTTOM OF PULL: 1/4"-20x2-1/4" FPHMS FINISH WASHER
5. INSTALL DEVICE ON DOOR PER DEVICE INSTRUCTIONS.

**CORRESPONDS TO TEMPLATES T-2001 AND W-2001**

DEVICE	"A"	"B"	"C"	DEVICE	"A"	"B"	"C"
(F)XX-R-DT	OMIT	OMIT	4-3/16"	(F)18-M-DT	OMIT	OMIT	4-3/16"
(F)XX-R-P	1-13/16"	OMIT	4-3/16"	(F)18-M-P	1-13/16"	OMIT	4-3/16"
(F)XX-M-DT	OMIT	OMIT	4-3/16"	(F)18-V-DT	OMIT	OMIT	4-3/16"
(F)XX-M-P	1-13/16"	OMIT	4-3/16"	(F)18-V-P	1/4"	OMIT	4-3/16"
(F)XX-V-DT	OMIT	OMIT	4-3/16"	(F)18-TPL-DT	OMIT	OMIT	4-3/16"
(F)XX-V-P	OMIT	31/32"	4-3/16"	(F)17-R-DT	OMIT	OMIT	3-1/4"
(F)XX-TPL-DT	OMIT	OMIT	4-3/16"	(F)17-M-P	2-1/16"	OMIT	3-1/4"
(F)18-R-DT	OMIT	OMIT	4-3/16"	(F)17-M-DT	OMIT	OMIT	3-1/4"
(F)18-R-P	1-13/16"	OMIT	4-3/16"	(F)17-V-DT	OMIT	OMIT	3-1/4"

**MONARCH**  
Exit Devices & Door Hardware

TECHNICAL SERVICE / CUSTOMER SERVICE 800-826-5972  
FAX-ON-DEMAND 877-454-9696

TITLE:  
**STANDARD TRIM - DT & P FUNCTIONS FOR (F)18, (F)XX & (F)17 SERIES DEVICES**

FOR STANDARD TRIM - T FUNCTION, SEE OTHER SIDE

DATE: 3-1-98  
DIRECTION SHEET - REV.  
**D-2001-3**