

941921-00

## **VON DUPRIN**<sub>®</sub>

Installation Instructions

## INSTRUCTIONS

Retro-fit One Piece Center Case Cover

1. Remove RH and LH center case covers. (Fig. 1)

2. Remove device from door.

3. Remove two 1/4-20 Cap Screws and center case cover. (Fig. 1)

4. Reinstall two 1/4-20 Cap Screws and secure with 1/4-20 hex nuts. (Fig. 2)

5. Attach cover mtg. bracket to mechanism case using two #12-24 x 1/2 Lg. Pan Phillips head screws(thread cutting).(Fig. 2)

6. Install cover bearing insert to bracket. (Be sure it stays in place during

handling). (Fig. 2)

7. Install device on door. (Adjust vertical rod devices).

8. Install one piece cover using four
#8-18 x 1/2 Lg. Flat Phillips head
screws (Fig. 2)





FIG. 1

CENTER CASE -

COVER

COVER

99



COVER MTG.

FIG. 2

## **RIM APPLICATION SHOWN**



