



- NOTE:
1. FOR DEVICE FUNCTIONS, SEE APPROPRIATE DEVICE TEMPLATES.
 2. SEE DEVICE TEMPLATE FOR MOUNTING HOLE LOCATIONS.
 3. A COORDINATOR MUST BE USED ON THE INACTIVE DOOR.

**RD45 STRIKE APPLICATION
FOR 1490 VERTICAL ROD &
1590 RIM DEVICE**

FALCON®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: **4270300002_a**

DATE: 12-23-14