



Vertical distance between holes

	A	B	C	D	E	F
Inch	1.5"	3"	2.5"	10"	7.25"	3.5"
mm	38.1	76.2	63.5	254	184	88.9

TWP Cutout

TWP requires an oval cutout 3/8" wide x 1-1/2" high in door and frame. (A round hole may also be used, 1-1/4" minimum diameter.)

83" = 41.5" and 85" = 42.5" from top of hinge.

NOTE: Deburr cutout to protect wires from abrasion.

Total Door Undersizing

- Single Square Edge Door – 15/32"
- Single Bevel Edge Door – 1/2"
- Pair of Doors, each leaf, Square Edge Door – 7/16"
- Pair of Doors, each leaf, Bevel Edge Door – 15/32"

Reinforcement recommended for six hole pattern at top and bottom of each leaf of hinge.

Hole Preparation (44 places)

Metal frame:

Standard self drilling self tapping screws - No drilling required
 Optional thread forming screws - #13 or 3/16" drill

Wood frame:

5/32" drill, 1.5" deep

© 2015 Allegion
 24638314-00 Rev. 01/15-b



112HD TWP 83" & 85"
 Concealed Continuous Hinge
 Profile Template



Note: Dimensions in [] are millimeters

Template Number 24638314(b)