



Total Door Undersizing

- Single Square Edge Door - 7/32"
- Single Bevel Edge Door - 1/4"
- Pair of Doors, each leaf, Square Edge Door - 3/16"
- Pair of Doors, each leaf, Bevel Edge Door - 7/32"

See installation instructions for reinforcement requirements.

Hole Preparation

Metal Frame:
#12-24 x 3/4" self-drilling tapping screws
#16 pilot drill is recommended for all holes

Wood Frame:
1/8" pilot drill

Vertical distance between holes

	A	B	C	D	E	F
Inch	1.50"	3.50"	4.00"	5.00"	5.50"	6.00"
mm	38.1	88.9	101.6	127	139.7	152.4



210XY 119" FULL SURFACE SWING CLEAR
CONTINUOUS HINGE TEMPLATE



NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE
NUMBER: 829744(A)

Date:
5-20-15