



#### Total Door Undersizing

Single Square Edge Door - 15/32"  
 Single Bevel Edge Door - 1/2"  
 Pair of Doors, each leaf, Square Edge Door - 7/16"  
 Pair of Doors, each leaf, Bevel Edge Door - 15/32"

See installation instructions for reinforcement requirements.

#### Hole Preparation

##### Metal Frame:

#12-24 x 3/4" self-drilling tapping screws  
 #16 pilot drill is recommended for all holes

##### Wood Frame:

1/8" pilot drill

#### Vertical distance between holes

	A	B	C	D
Inch	1.50"	2.50"	3"	10"
mm	38.1	63.5	76.2	254.0

**IVES**

026XY 95" FULL MORTISE  
 CONCEALED, NARROW FRAME  
 CONTINUOUS HINGE TEMPLATE

**ALLEGION**

NOTE: DIMENSIONS IN ( ) ARE IN MILLIMETERS

TEMPLATE  
 NUMBER: 829710(B)

Date:  
 8-12-16