

Strikes Model 10-091



Jamb Type: Wood or Metal

Style: Mortise, Armor Front Strike (handed to inactive door)

Standard for: Optional for:

NOTES:

1. Lock Case cavity and Strike shown for dimensions only

10-091 Detail

- 2. Prepare door cut-outs as indicated under Door Detail
- 3. Dimensions shown are maximum for this product
- 4. Measure backset from Centerline of Door Edge

Door Left Hand and Right Hand and Outside of RH Door Inside of RH Door Right Hand Reverse Left Hand Reverse Edge Bevel Bevel Ф Ф Cut-out for Lip 4.000" shown for RH and (102)LHRB doors. 3.375 For LH and RHRB (66)doors, place on other side. 8.000" (203).090" (2) Ç .218" (6) 2.685" Ф Ф (68)Φ 1.250" (32)4.437" #12 - 24 WMS (M6) ← or → (113)in two places 1.0625" (27)1.546" (39) Flat

Door Detail

Dimensions shown in parentheses () are in millimeters.

Door preparation template

J913