




## INSTALLATION TEMPLATE H170 DUMMY TRIM

Mark mounting screw holes  
in 4 places by arrows.

**2 $\frac{3}{4}$ " BACKSET**

**2 $\frac{3}{8}$ " BACKSET**



Height line for  
center line of  
door knob.

## INSTALLATION TEMPLATE H170 DUMMY TRIM

Mark mounting screw holes  
in 4 places by arrows.



**2<sup>3</sup>/<sub>4</sub>" BACKSET**

**2<sup>3</sup>/<sub>8</sub>" BACKSET**

↑  
Height line for  
center line of  
door knob.



**INGERSOLL-RAND**  
ARCHITECTURAL HARDWARE

©2000 Schlage Lock Co.  
Printed in USA 2/00  
P509-216