

Measure desired backset (edge of door to location of mounting screw holes).

Locate heightline to mark for center of lock (suggested height for center of lock is 38" from floor). If installation is for a pair of doors, match the height and backset of the lock on the active door.

Place the template at the correct height and backset and mark through template for (2) mounting screws.

Place dummy trim and housing into position and secure to door with provided screws.

Slide rose over lever and snap into place on housing.

© 2014 Allegion
Printed in U.S.A.
P513-049 Rev. 01/14-b



TEMPLATE FOR INSTALLING THIS

SCHLAGE

DUMMY TRIM

P513-049

2 3/4" BACKSET

2 3/8" BACKSET

HEIGHTLINE

IMPORTANT:

Select the correct backset to match the installation of other locks on the project. If installing on the inactive leaf of a pair of doors, measure from door edge to center of rose on the active door.

FOLD ON EDGE OF DOOR AT DESIRED BACKSET

