



L-Series Door Template Index (Page 1 of 2)

Lock Functions	Rose Trim		Escutcheon Trim		HSLR Trim	
	Wood	Metal	Wood	Metal	Wood	Metal
L/LV/LM/LMV 9000 Series Lock Case Dimensions	L1				-	
L400 Series Lock Case Dimensions	L2				-	
LM9200 Lock Case Dimensions	L3				-	
L9000 Series HSLR	-				L4	
L9010, L9110	L892	L893	L898	L899	L965	L966
LM9310	-	L893	-	L899	-	-
L9025	L808	L809	L810	L811	-	-
L9026	L812	L813	L814	L815	-	-
L/LV9040, L/LV9044, L/LV9440, L/LV9444	L894	L895	L900	L901	L965	L966
L0170	L739	L781	L741	L782	-	-
L0172	L743	L744	L745	L746	-	-
L9175	L851	L806	L859	L855	-	-
LM9325	-	L806	-	L855	-	-
L9176	L852	L807	L860	L856	-	-
L/LV/LM/LMV9050, L/LV/LM/LMV9056, L/LV9453, L/LV9456, L9473, L/LV9480, L/LV9485	L896	L897	L826	L827	L965	L966
LM/LMV9350, LM/LMV9356	-	L897	-	L827	-	-
L/LV9060, L/LV/LM/LMV9071, L/LV9077, L/LV9082 EL/EU, L/LV9457, L/LV9458, L9466, L/LV9482	L816	L817	L828	L829	L965	L966
LM/LMV9371		L817		L829	-	-
L/LV9070, L/LV9076, L/LV9080, L/LV9080 EL/EU, L9465	L905	L906	L907	L908	L965	L966
LM/LMV9370, LM/LMV9380		L906		L908	-	-
L/LV9486, L/LV9496	L820	L821	-	-	-	-
L9460, L9462, L9463, L9464 (Deadbolt only)	L902	L903	-	-	-	-
L9412	L967	L968	L911	L912	-	-
L460, L462, L463, L464, L480, L496 (Deadbolt, small chassis)	L909	L910	-	-	-	-
Mounting active trim, one side, L283-150 (use with appropriate lock function template)	L904		-	-	-	-
L9090, L9091	L918	L916	L917	L915	-	-
L9092, L9093	L922	L920	L921	L919	L965	L966
L9094, L9095, L9494, L9495	L926	L924	L925	L923	L965	L966
L9492, L9493	L961	L962	L963	L964	L965	L966
LM9210, LM9210F, LM9210M	L928	L944	L927	L943	-	-
LM9225, LM9225F, LM9225M	L930	L946	-	-	-	-
LM9250, LM9250F, LM9250M, LM9256, LM9256F, LM9256M	L932	L948	L931	L947	-	-
LM9270, LM9270F, LM9270M, LM9280, LM9280F, LM9280M	L934	L950	L933	L949	-	-
LM9271, LM9271F, LM9271M	L936	L952	L935	L951	-	-
LM9290 EL/EU, LM9291 EL/EU	L938	L954	L937	L953	-	-
LM9292 EL/EU, LM9293 EL/EU	L940	L956	L939	L955	-	-
LM9294 EL/EU, LM9295 EL/EU	L942	L958	L941	L957	-	-
LM9200 LBL (less bottom latch)	L959	L960	L959	L960	-	-

L-Series Door Template Index (Page 2 of 2)

Strikes	Wood jamb	Metal jamb
10-072, 10-087, ANSI, square corner	J918	J919
10-073, 10-078, ANSI, square corner, deadbolt, box	J920	J921
10-075, Mortise, square corner, 1/2" (13 mm) rabbeted, no box	J557	
10-079, Mortise, square corner, deadbolt, no lip, box	J922	J923
10-091, Mortise, armor front strike	J913	