



- NOTE: 1. FOR DEVICE FUNCTIONS SEE APPROPRIATE DEVICE TEMPLATES.
2. SEE DEVICE TEMPLATE FOR MOUNTING HOLE LOCATIONS.
3. A COORDINATOR MUST BE USED ON THE INACTIVE DOOR.

## 1609 Strike Application for 98/99 Vertical Rod & 98/99 Rim Devices (Panic Device Only)

**VON DUPRIN®**

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

30229\_a

DATE: 05-28-13