



IT IS RECOMMENDED THE MOUNTING HOLES BE PREPARED IN THE FIELD

210 K Series Trim

VON DUPRIN®

NOTES: See Master Sheet #10001 For Suggested Reinforcing

TEMPLATE NUMBER:

20018_a

DATE:
05-22-13