



- a. After closing door with bottom latch installed, mark the location the bottom latch bolt is contacting the threshold.
- b. Drill a $\frac{3}{4}$ " diameter hole in the threshold.

DEVICE APPLICATION SCHEDULE

33/3549A & 33/3549A-F SERIES DEVICE

THRESHOLD PREPARATION FOR ALUMINUM DOOR

VON DUPRIN®

TEMPLATE NUMBER: 24143075_b

DATE: 9-21-16