



379L and 379L-BE Control
(Wood Door)

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: 931006-00_a

DATE: 12-28-17

E379L-BE: USE 379L PREP AND 3/8" RACEWAY FROM TOP OF CUTOUT.