



NOTES:

1. FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE TRIM TEMPLATE
2. MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR,
3. SEE TEMPLATE #30038 IN HOLLOW METAL TEMPLATE BOOK FOR 338 STRIKE.

LHR APPLICATION SHOWN,
RHR APPLICATION OPPOSITE

* SEE 556NL TRIM TEMPLATE W20041 FOR PULL SIDE FACE CUTOUT

**5547WDC & 5547WDC-F SERIES
x 556NL
VERTICAL ROD DEVICES (WOOD DOOR)**

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

01_186_00_b

DATE:
02-12-18