



LHR APP. SHOWN  
RHR APP. OPPOSITE

NOTES:  
1. SEE SHT 2 FOR APPLICATION SCHEDULE.

## 6212 WF Electric Strike Mortise Wood Frame Application

# VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: **W30222\_b Sht 1**

DATE: 06-05-15

# 6212 WF ELECTRIC STRIKE MORTISE/CYLINDRICAL APPLICATION SCHEDULE

PRODUCT MANUFACTURER	PRODUCT APPLICATION	THROW	DIM "B"	DIM "C"
VON DUPRIN	7500 MORTISE	3/4"	3/8"	
ADAMS RITE	4510	1/2"	3/8"	
ADAMS RITE	4710	5/8"	3/8"	
ARROW	A & B MORTISE	3/4"		3/8"
BALDWIN	6000 MORTISE	3/4"		11/16"
BEST	24H/30 SERIES MORTISE	3/4"		3/8"
*CORBIN	9000 SERIES MORTISE	3/4"		3/8"
FALCON	M2300/M2500 MORTISE	3/4"		7/16"
FALCON	M3300/M3500 MORTISE	5/8"		7/16"
FALCON	M2600 MORTISE	3/4"	7/16"	
FALCON	M3600 MORTISE	5/8"	7/16"	
GENERAL	MORTISE	3/4"		7/8"
PRECISION	MORTISE	3/4"		7/16"
*RUSSWIN	5000 MORTISE	3/4"		3/8"
SARGENT	77 MORTISE	5/8"		7/16"
SARGENT	18-77/81 MORTISE	3/4"		3/8"
SARGENT	900 MORTISE	3/4"		7/16"
SCHLAGE	K30/40/50/60 MORTISE	3/4"		7/8"
SCHLAGE	L9000 MORTISE	3/4"		7/8"
YALE	8600 MORTISE	5/8"		3/8"
YALE	7030/7130/8700 MORTISE	3/4"		3/8"
GLYNN-JOHNSON	HL6 CYLINDRICAL	1/2"	0"	0"
BALDWIN	CYLINDRICAL	1/2" - 3/4"	0"	0"
BEST	CYLINDRICAL	3/8" - 3/4"	0"	0"
FALCON	CYLINDRICAL	1/2" - 3/4"	0"	0"
RUSSWIN/CORBIN	CYLINDRICAL	1/2" - 3/4"	0"	0"
SARGENT	CYLINDRICAL	1/2" - 3/4"	0"	0"
SCHLAGE	CYLINDRICAL	3/8" - 3/4"	0"	0"
YALE	CYLINDRICAL	1/2" - 3/4"	0"	0"

**REPLACES:**

VON DUPRIN 3146 ELECTRIC STRIKE

**NOTES:**

1. DEADLATCH NOT GUARANTEED ON CYLINDRICAL APPLICATIONS.
2. MONITORING COULD BE AFFECTED BY DOOR/FRAME PREPARATION.
3. SIGNAL TRIPPER FUNCTION WITH 3/8" THROW BOLTS IS NOT RECOMMENDED.
- \*4. DO NOT USE FOR LOCKS WITH DEADBOLTS.

**6212 WF Electric Strike  
Wood Frame Application**

**VON DUPRIN®**

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: **W30222\_b Sht 2**

DATE: 06-05-15