

# TEMPLATE INSTRUCTIONS

(For Light-Duty Escutcheon Lever Trim Use)

REV 1:12/2010

For backset, see page 1  
of installation instructions  
for details on  
DOOR APPLICATIONS

For backset, see page 1  
of installation instructions  
for details on  
DOOR APPLICATIONS

TRIM MOUNTING HOLES X2  
DRILL  $\varnothing 7/16"$  (11mm) HOLE ON  
OUTSIDE FACE OF DOOR

TRIM ACTUATING SHAFT HOLE  
DRILL  $\varnothing 1/2"$  (13mm) THROUGH HOLE

TRIM  $\mathcal{L}$   
CORRESPONDS TO EXIT DEVICE  $\mathcal{L}$

2-7/8"  
[73mm]

EDGE OF DOOR

LHR

OUTSIDE FACE OF DOOR

TRIM MOUNTING HOLES X2  
DRILL  $\varnothing 7/16"$  (11mm) HOLE  
ON OUTSIDE FACE OF DOOR

TRIM ACTUATING SHAFT HOLE  
DRILL  $\varnothing 1/2"$  (13mm) THROUGH HOLE

TRIM  $\mathcal{R}$   
CORRESPONDS TO EXIT DEVICE  $\mathcal{R}$

2-7/8"  
[73mm]

RHR

OUTSIDE FACE OF DOOR

