



**INSTALLATION INSTRUCTIONS**

1. PREPARE INSIDE FACE OF DOOR FOR DEVICE.
  - A. SEE DEVICE DIRECTIONS FOR LOCATIONS OF VERT. AND DEVICE REF. CENTERLINES.
2. PREPARE OUTSIDE FACE OF DOOR FOR TRIM.
  - A. TRANSFER VERT. AND DEVICE REF. CENTERLINES FROM INSIDE FACE TO OUTSIDE FACE OF DOOR. BE SURE VERT. CENTERLINE IS PARALLEL TO EDGE OF DOOR.
  - B. LOCATE AND PREPARE ALL HOLES AS INDICATED.
3. INSTALL TRIM ON DOOR AND CUT KNOB SPINDLE TO SIZE.
  - A. TRIM MOUNTING.
    - FOUR STUDS: ARE THRU-BOLTED TO DEVICE WHEN DEVICE IS INSTALLED.
  - B. CUT KNOB SPINDLE.
    - RIM, VERTICAL & THREE POINT LATCH: KNOB SPINDLE TO EXTEND 5/8"-3/4" BEYOND DOOR SKIN.
    - MORTISE: KNOB SPINDLE TO BE INSIDE DOOR SKIN BY 1/2".
4. ASSEMBLE CYLINDER (IF REQUIRED).
  - A. IF USING MORTISE CYLINDER, INSTALL CYLINDER TO MORTISE LOCK.
  - B. IF USING RIM CYLINDER, CUT TAILPIECE TO EXTEND 3/8" BEYOND INSIDE FACE OF DOOR.
5. INSTALL DEVICE ON DOOR PER DEVICE INSTRUCTIONS.

D-2065-a Copyright © 2008 Ingersoll-Rand Company Limited

DEVICE	"A"	"B"	"C"	DEVICE	"A"	"B"	"C"
(F)XX-R-K	OMIT	1-1/4"	3-3/16"	(F)18-R-K	OMIT	1-1/4"	3-3/16"
(F)XX-R-K (BE)	OMIT	OMIT	3-3/16"	(F)18-R-K (BE)	OMIT	OMIT	3-3/16"
(F)XX-R-K (NL)	OMIT	1-1/4"	3-3/16"	(F)18-R-K (NL)	OMIT	1-1/4"	3-3/16"
(F)XX-R-K DT	OMIT	OMIT	3-3/16"	(F)18-R-K DT	OMIT	OMIT	3-3/16"
(F)XX-R-P x KE DT	1-1/4"	OMIT	3-3/16"	(F)18-R-P x KE DT	1-1/4"	OMIT	3-3/16"
(F)XX-R-K2	1-1/4"	OMIT	3-3/16"	(F)18-R-K2	1-1/4"	OMIT	3-3/16"
(F)XX-R-K(20.C.)	1-1/4"	1-1/4"	3-3/16"	(F)18-R-K(20.C.)	1-1/4"	1-1/4"	3-3/16"
(F)XX-M-K	1-1/4"	OMIT	1-1/4"	(F)18-M-K	1-1/4"	OMIT	1-1/4"
(F)XX-M-K (BE)	OMIT	OMIT	1-1/4"	(F)18-M-K (BE)	OMIT	OMIT	1-1/4"
(F)XX-M-K (NL)	1-1/4"	OMIT	1-1/4"	(F)18-M-K (NL)	1-1/4"	OMIT	1-1/4"
(F)XX-M-K DT	OMIT	OMIT	1-1/4"	(F)18-M-K DT	OMIT	OMIT	1-1/4"
(F)XX-M-P x KE DT	1-1/4"	OMIT	1-1/4"	(F)18-M-P x KE DT	1-1/4"	OMIT	1-1/4"
(F)XX-M-K2	1-1/4"	OMIT	1-1/4"	(F)18-M-K2	1-1/4"	OMIT	1-1/4"
(F)XX-V-K	1-1/4"	OMIT	1-1/4"	(F)18-V-K	1-1/4"	OMIT	1-1/4"
(F)XX-V-K (BE)	OMIT	OMIT	1-1/4"	(F)18-V-K (BE)	OMIT	OMIT	1-1/4"
(F)XX-V-K (NL)	1-1/4"	OMIT	1-1/4"	(F)18-V-K (NL)	1-1/4"	OMIT	1-1/4"
(F)XX-V-K DT	OMIT	OMIT	1-1/4"	(F)18-V-K DT	OMIT	OMIT	1-1/4"
(F)XX-TPL-K	1-1/4"	OMIT	1-1/4"	(F)18-TPL-KE	1-1/4"	OMIT	1-1/4"
(F)XX-TPL-K (BE)	OMIT	OMIT	1-1/4"	(F)18-TPL-KE (BE)	OMIT	OMIT	1-1/4"
(F)XX-TPL-K (NL)	1-1/4"	OMIT	1-1/4"	(F)18-TPL-KE (NL)	1-1/4"	OMIT	1-1/4"
(F)XX-TPL-K DT	OMIT	OMIT	1-1/4"	(F)18-TPL-KE DT	OMIT	OMIT	1-1/4"

FALCON<sup>®</sup>

TITLE:

**K TRIM FOR  
(F)18 & (F)XX SERIES DEVICES**



**D-2065**