



Total Door Undersizing

- Single Square Edge Door - 15/32"
- Single Bevel Edge Door - 1/2"
- Pair of Doors, each leaf, Square Edge Door - 7/16"
- Pair of Doors, each leaf, Bevel Edge Door - 15/32"

See installation instructions for reinforcement requirements.

Hole Preparation

Metal Frame:
 #12-24 x 3/4" self-drilling tapping screws
 #16 pilot drill is recommended for all holes

Wood Frame:
 1/8" pilot drill

Vertical distance between holes

| | A | B | C | D |
|-------------|-------|-------|------|-------|
| Inch | 1.50" | 2.50" | 3" | 10" |
| mm | 38.1 | 63.5 | 76.2 | 254.0 |



040XY 83" & 85" FULL MORTISE, WIDE THROW CONTINUOUS HINGE TEMPLATE



NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE NUMBER: 829719(A)

Date: 6-3-15