



Be sure to configure access point AUX/REX settings to "REX w/o Unlatch".

Optional REX input on RC-04 is for "Unauthorized Entry Alert" or remote door release only.

All required life-safety request to exit devices must break the positive leg of the lock power circuit as shown above.