

## Ives Exterior Door Hardware Template Index

### Crash stop templates

Function	Template Number
15 crash stop	<a href="#">530</a>
CS115 crash stop	<a href="#">INST.CS115</a>

### Box plate templates

Function	Template Number
618, 619, 623, 624 and 625 letter box plate	<a href="#">2179</a>
620, 621 and 622 with 601 box sleeve	<a href="#">413</a>
626, 627, 628 and 629 letter box plate with 600 sleeve	<a href="#">262</a>
650, 651 and 652 letter box plate	<a href="#">702</a>

### Viewer templates

Function	Template Number
U696 and U697 one-way viewer	<a href="#">2218</a>
698 and U698 one-way viewer	<a href="#">2217</a>
700, U700, 701 and U701 viewer	<a href="#">650</a>

### Door knocker templates

Function	Template Number
763, U763, 764 and U764 knocker	<a href="#">308</a>
771 and U771 door knocker	<a href="#">594</a>
774 and U774 door knocker	<a href="#">594</a>
3115 Aristocrat knocker	<a href="#">108138</a>

### Door knocker and viewer templates

Function	Template Number
771 - 774 knocker x UL viewer	<a href="#">2283</a>
3100 knocker and viewer	<a href="#">2311</a>
3101 knocker and viewer	<a href="#">2312</a>
3102 knocker and viewer	<a href="#">2313</a>
3107 knocker and viewer	<a href="#">2315</a>
3122 knocker and viewer	<a href="#">108142</a>
3125 knocker and viewer	<a href="#">2320</a>

### Door chime templates

Function	Template Number
780 door chime	<a href="#">2376</a>

### Door latch templates

Function	Template Number
980 storm door latch	<a href="#">2004</a>

### Lock guard templates

Function	Template Number
LG1 and LG7 lock guard	<a href="#">829678</a>
LG10, LG11, LG12, LG13 and LG14 lock guard	<a href="#">INST.LG1014</a>