



Center Case Retrofit / Replacement

(AX) 98/99-2, (AX) 98/99-2SI, **VON DUPRIN**® (AX) XP99-2, (AX) XP99-2SI


Installation Instructions






1 Remove existing exit device from door.

Note: Disconnect device wiring if necessary.




2 Prepare door if necessary.




Door Cutout for XP98/99-2SI or 98/99-2SI "Double Cylinder" Option Wood 1/4" (6 mm) Deep 21/4" (57 mm) 4 places 13/16" (21 mm) 13/6" (35 mm) Device and Strike

3 Remove old center case.


A. Slide mechanism case back approximately 5".




B. Remove slic pin and two screws to remove old center case.



4 Leave the NL Drive Screw in master cam as shipped in new center case.




5 Attach new center case to device as shown.




WARNING

New slic pin must be installed securely. If pin comes out, door will not open properly.






For 98/99-2SI models with Classroom Security Indicator, apply supplied labels above and below cylinder to match door handing, and • label on indicator.



① Manually affix the label:

Ensure surface is clean of dirt, dust, or oils. Clean with alcohol if necessary.


Peel the label from the paper backing and apply to the surface. Minimize handling when applying and use pressure to burnish label to surface. The adhesive will require up to 8 hours to achieve the proper bond.



Front of Device


From front side of device, insert tailpiece guide into master cam. It will snap into location.

8 Slide mechanism case forward and install bracket.




9 Check latch function as shown.

A. Depress auxiliary bolt and check latch bolt. Latch bolt should be locked and will not move while auxiliary bolt is depressed.



B. With auxiliary bolt still depressed, press and hold device push bar. Press latch bolt from top and bottom. It should depress freely in both directions.




Note about the XP latch operation

The XP latchbolt operates differently from a standard latchbolt. When the pushbar is depressed, the latchbolt does not retract. This is normal because the XP

normal because the XP latchbolt can swivel in both directions.



10 Reinstall device.



11 Perform operational check.


(i) Important!

A. With door closed, push against door without touching device.


Device should NOT allow door to open.




B. With door closed, push device push bar. Device should allow door to open.



C. If device does not function as described, adjust strike position and continue operational check until device functions as described above.






909 Strike for XP Product



Customer Service



BEGINNING SHEET FOLDED SHEET

Additional Notes:	
1. None	

	Revision History					Revision Description:				
А	В	С	D	E	F	D > Revised document				
58294	58807	61680	65544							
Material	Material White Paper					Edited By	Approved By	EC Number	Release Date	
						J. Ellis	M. Roberts	65544	10-22-20	
	 printed two sides on 11x17 sheet printed black folded into 8.5x11 4-page booklet tolerance ± .13 					Title 99-2/2-SI Center case retrofit/replacement instruction				
3. folded 4. tolerar						Creation Date xx-xx-xx	Number 941363-00		Revision D	
	5. printed in country may vary6. drawings not to scale					Created By J. Ellis	Activity 3899 Hancock Expwy			
					Software: InDesign CS6	Security, CO 80911		Allegion 2020		