


1277 Coordinator and 1278 Opening Bar Preparation

Metal Door, LHR Shown, RHR Opposite



NOTE:
When mounting opening bar on inactive door, adjust so it will clear the active door astragal when the active door is held open by a coordinator.

TEMPLATE
T-4018-a