



Important – Read This First

- Always refer to manufacturer instructions, this drawing is a recommendation and site characteristics vary.
- When utilizing 12vdc from a PoE powered RC-04 verify power calculation to ensure enough power is available for all devices.
- Some adjustment of the timing will be necessary by adjusting the potentiometers, installing the device at default values will result in errors.
- Read and follow instructions for separate power supply that is specific to the electrified panic bar

RC-04.		
POE.EDK.ElectrifiedPanic.REX.DSM.ADA-CADS1		
Dwg No:	Sheet 1	of 1
Date: 11-28-2017	Drawn By: David Tamarchenko	Version: 1.00.00
ISONAS PURE IP ACCESS CONTROL		4750 Walnut Street Suite 110 Boulder, CO 80301 www.isonas.com