


# SCHLAGE®

P509-272

## 40-069 Maintenance Kit

Part No.	Description	Qty.	Slot No.
C303-006-SS3	Slide and Roller	2	1
P509-272	Sheet, component parts	1	2
C503-314-604	Seat, Slide Spring	2	3
C503-019-SS3	Spring, Slide	4	3
C604-191-SS3	Spring, Catch, Slide	2	4
C604-187-604	Catch, Slide	2	5
C604-188-604	Catch, Slide	2	6
C604-190-604	Catch, Slide	2	6
C102-840-604	Cam and Plug	2	7
C203-948-604	Spindle and Catch	2	8
C503-008-604	Cotter Pin	10	9
C604-273-SS3	Cotter Pin	5	9
C603-569-BZ	Retainer	10	10
C503-605-PLA	Friction Ring	5	11
C203-944	Spindle and Catch	2	12
C303-029-455	Screw Pack	2	13
C303-029-479	Screw Pack	2	13
C303-029-498	Screw Pack	2	13
C303-029-613	Screw Pack	2	13
C303-007-606	Screw Pack	2	14
C604-333-604	Driver I.C.	5	14
C503-400-SS3	Pin	2	15
M504-413-PLA	Installation Tool	1	16
M504-410-603/604	Wrench	3	17
C303-028-455	Screw Pack	2	18
C303-028-479	Screw Pack	2	18
C303-028-498	Screw Pack	2	18
C303-028-613	Screw Pack	2	18
C203-034-604	Spindle and Catch	2	19



Part No.	Description	Qty.	Slot No.
C303-421-606	Screw Pack	2	20
M504-341-604	Spanner Wrench	3	21
C604-354-604	Hub, Bushing (castle nut)	3	22
C604-330-PLA	Plug, Lever	4	22
C503-371-BR	Plunger	3	23
C503-362-604	Plunger	3	23
C203-733-604	Plug	2	24
C102-837-604	Cam and Plug	2	24
C503-308-SS3	Spring Anchor	2	25
C503-964-604	Sleeve Plunger	6	Bottom
C503-965-604	Sleeve Plunger	6	Bottom
C503-963-604	Sleeve Plunger	6	Bottom
C603-500-604	Housing, slide	1	Bottom
C604-312-604	Anchor	2	Bottom
C303-035-428	Inside Spring Cage	2	Bottom
C303-036-428	Outside Spring Cage	2	Bottom

 **Security & Safety**

©2004 Ingersoll-Rand Co.  
Printed in Country  
P509-272 Rev. 04/04-c