




P515-181



### 40-097 Maintenance Kit

Part No.	Description	Qty.	Slot No.
N523-055	Plate, Anti-Rotation	2	1
D500-000	Spacer, SFIC	5	2
N523-020	Cylinder	3	2
N523-091	Driver, SFIC	5	2
N523-127	Driver, IC	5	2
N523-149	Slide	2	4
N523-025	Clip, Slide	2	4
N523-021	Screw, Mounting	4	5
N523-092	Screw, Machine Oval Head	4	5
C604-187	Catch, slide	2	6
C604-188	Catch, Slide	2	6
N523-084	Bar, Key	2	7
N523-054	Plate, Adjustment	2	8
N123-007	Keycam Assembly	2	9
N123-008	Keycam Assembly	2	10
N123-009	Keycam Assembly	2	11
N123-010	Keycam Assembly	2	12
N123-011	Keycam Assembly	2	13
N123-012	Keycam Assembly	2	13
N123-013	Keycam Assembly	2	14
021415-000-604	Spanner Wrench	1	15
N123-028	Plunger Assembly	3	16
N123-017	Plunger Assembly	3	17
N523-056	Spindle, Inside	2	18
N523-013	Spindle, Outside	2	19
N523-019	Spindle, Outside, Electrified	2	20
N123-020	Package, Screw	2	21
N123-040	Package, Screw	2	22
N523-015	Hub, Inside	2	23
N523-016	Hub, Inside	2	24
N523-014	Housing, Outside	2	25



Part No.	Description	Qty.	Slot No.
63-104	Springcage Assembly, Dummy	1	Bottom
M504-413	Installation Tool	1	Bottom
N123-021	Springcage Assembly, Inside	1	Bottom
N123-022	Springcage Assembly, Outside	1	Bottom
N123-032	Springcage Assembly, Inside	1	Bottom
N123-043	Springcage Assembly, Outside	1	Bottom
N123-056	Springcage Assembly, SFIC, Outside	1	Bottom
N123-057	Springcage Assembly, SFIC, Inside	1	Bottom



©2010  
 Schlage Lock Company  
 (800) 847-1864  
 Printed in Country  
 P515-181 Rev. 5/10-e