

98/99 Series Trims, Controls & Strikes Template Index Hollow Metal Door Applications

98/99 Trims		
Trim	Used with	Template
110NL Cylinder Assembly	98NL-OP, 99NL-OP, 98NL-OP-F, 99NL-OP-F	40022
	9827NL-OP, 9927NL-OP, 9827NL-OP-F, 9927NL-OP-F	
	9847NL-OP, 9947NL-OP, 9847NL-OP-F, 9947NL-OP-F	
	9849NL-OP, 9949NL-OP, 9849NL-OP-F, 9949NL-OP-F	
392-7	98DT, 99DT, 98DT-F, 99DT-F	20447
	98NL-OP, 99NL-OP, 98NL-OP-F, 99NL-OP-F	
	9827DT, 9927DT, 9827DT-F, 9927DT-F	
	9827NL-OP, 9927NL-OP, 9827NL-OP-F, 9927NL-OP-F	
	9847DT, 9947DT, 9847DT-F, 9947DT-F	
	9847NL-OP, 9947NL-OP, 9847NL-OP-F, 9947NL-OP-F	
	9875DT, 9975DT, 9875DT-F, 9975DT-F	
	9875NL-OP, 9975NL-OP, 9875NL-OP-F, 9975NL-OP-F	
	9849DT, 9949DT, 9849DT-F, 9949DT-F	
	9849TL, 9949TL, 9849TL-F, 9949TL-F	
696DT Trim	98DT, 99DT, 98DT-F, 99DT-F	20101
	9827DT, 9927DT, 9827DT-F, 9927DT-F	
	9847DT, 9947DT, 9847DT-F, 9947DT-F	
	9875DT, 9975DT, 9875DT-F, 9975DT-F	
	9849DT, 9949DT, 9849DT-F, 9949DT-F	
696DT Trim	330/350 Push Bar Trim	20105
696NL-M Trim	9875NL, 9975NL, 9875NL-F, 9975NL-F	20104

98/99 Trims		
Trim	Used with	Template
696NL-R/V Trim	98NL, 99NL, 98NL-F, 99NL-F	20102
	9827NL, 9927NL, 9827NL-F, 9927NL-F	
	9847NL, 9947NL, 9847NL-F, 9947NL-F	
	9849NL, 9949NL, 9849NL-F, 9949NL-F	
696TP-M 696TP-M-BE Trim	9875TP, 9975TP, 9875TP-F, 9975TP-F	20103
696TP-R/V 696TP-R/V- BE Trim	98TP, 99TP, 98TP-F, 99TP-F	20100
	9827TP, 9927TP, 9827TP-F, 9927TP-F	
	9847TP, 9947TP, 9847TP-F, 9947TP-F	
	9849TP, 9949TP, 9849TP-F, 9949TP-F	
697DT Trim	98DT, 99DT, 98DT-F, 99DT-F	20101
	9827DT, 9927DT, 9827DT-F, 9927DT-F	
	9847DT, 9947DT, 9847DT-F, 9947DT-F	
	9875DT, 9975DT, 9875DT-F, 9975DT-F	
	9849DT, 9949DT, 9849DT-F, 9949DT-F	
697DT	330/350 Push Bar Trim	20105
697NL-M Trim	9875NL, 9975NL, 9875NL-F, 9975NL-F	20104
697NL-R/V Trim	98NL, 99NL, 98NL-F, 99NL-F	20102
	9827NL, 9927NL, 9827NL-F, 9927NL-F	
	9847NL, 9947NL, 9847NL-F, 9947NL-F	
	9849NL, 9949NL, 9849NL-F, 9949NL-F	
697TP-M 697TP-M-BE Trim	9875TP, 9975TP, 9875TP-F, 9975TP-F	20103

98/99 Trims		
Trim	Used with	Template
697TP-R/V 697TP-R/V- BE Trim	98TP, 99TP, 98TP-F, 99TP-F	20100
	9827TP, 9927TP, 9827TP-F, 9927TP-F	
	9847TP, 9947TP, 9847TP-F, 9947TP-F	
	9849TP, 9949TP, 9849TP-F, 9949TP-F	
99EO Trim	98EO, 99EO, 98EO-F, 99EO-F	20269
	9827EO, 9927EO, 9827EO-F, 9927EO-F	
	9847EO, 9947EO, 9847EO-F, 9947EO-F	
	9875EO, 9975EO, 9875EO-F, 9975EO-F	
	9849EO, 9949EO, 9849EO-F, 9949EO-F	
990DT Trim	98DT, 99DT, 98DT-F, 99DT-F	20268
	9827DT, 9927DT, 9827DT-F, 9927DT-F	
	9847DT, 9947DT, 9847DT-F, 9947DT-F	
	9875DT, 9975DT, 9875DT-F, 9975DT-F	
	9849DT, 9949DT, 9849DT-F, 9949DT-F	
990DT Trim	330/350 Push Bar	20285
990NL-M Trim	9875NL, 9975NL, 9875NL-F, 9975NL-F	20271
990NL-R/V Trim	98NL, 99NL, 98NL-F, 99NL-F	20267
	9827NL, 9927NL, 9827NL-F, 9927NL-F	
	9847NL, 9947NL, 9847NL-F, 9947NL-F	
	9849NL, 9949NL, 9849NL-F, 9949NL-F	
990TP-M 990TP-M-BE Trim	9875TP, 9975TP, 9875TP-F, 9975TP-F	20270
990TP-R/V 990TP-R/V- BE Trim	98TP, 99TP, 98TP-F, 99TP-F	20265
	9827TP, 9927TP, 9827TP-F, 9927TP-F	
	9847TP, 9947TP, 9847TP-F, 9947TP-F	
	9849TP, 9949TP, 9849TP-F, 9949TP-F	

98/99 Trims		
Trim	Used with	Template
991K-M Trim	9875K, 9975K, 9875K-F, 9975K-F	20280
991K-M-BE Trim	9875K-BE, 9975K-BE, 9875K-BE-F, 9975K-BE-F	20273
991K-NL-M Rigid Trim	9875NL, 9975NL, 9875NL-F, 9975NL-F	20281
991K-DT Trim	98K-DT, 99K-DT, 98K-DT-F, 99K-DT-F	20274
	9827K-DT, 9927K-DT, 9827K-DT-F, 9927K-DT-F	
	9847K-DT, 9947K-DT, 9847K-DT-F, 9947K-DT-F	
	9875K-DT, 9975K-DT, 9875K-DT-F, 9975K-DT-F	
991K-R/V Trim	98K, 99K, 98K-F, 99K-F	20272
	9827K, 9927K, 9827K-F, 9927K-F	
	9847K, 9947K, 9847K-F, 9947K-F	
991K-R/V-BE Trim	98K, 99K, 98K-F, 99K-F	20273
	9827K, 9927K, 9827K-F, 9927K-F	
	9847K, 9947K, 9847K-F, 9947K-F	
991K-NL-R/V Rigid Trim	98NL, 99NL, 98NL-F, 99NL-F	20275
	9827NL, 9927NL, 9827NL-F, 9927NL-F	
	9847NL, 9947NL, 9847NL-F, 9947NL-F	
992L-M Trim	9875L, 9975L, 9875L-F, 9975L-F	20280
992L-M-BE Trim	9875L, 9975L, 9875L-F, 9975L-F	20273
992L-NL-M Rigid Trim	9875NL, 9975NL, 9875NL-F, 9975NL-F	20281
992L-DT Trim	98L-DT, 99L-DT, 98L-DT-F, 99L-DT-F	20274
	9827L-DT, 9927L-DT, 9827L-DT-F, 9927L-DT-F	
	9847L-DT, 9947L-DT, 9847L-DT-F, 9947L-DT-F	
	9875L-DT, 9975L-DT, 9875L-DT-F, 9975L-DT-F	
992L-DT	330/350 Push Bar Trim	20293

98/99 Trims		
Trim	Used with	Template
992L-R/V Trim	98L, 99L, 98L-F, 99L-F	20272
	9827L, 9927L, 9827L-F, 9927L-F	
	9847L, 9947L, 9847L-F, 9947L-F	
992L-R/V-BE Trim	98L, 99L, 98L-F, 99L-F	20273
	9827L, 9927L, 9827L-F, 9927L-F	
	9847L, 9947L, 9847L-F, 9947L-F	
992L-NL-R/V Rigid Trim	98NL, 99NL, 98NL-F, 99NL-F	20275
	9827NL, 9927NL, 9827NL-F, 9927NL-F	
	9847NL, 9947NL, 9847NL-F, 9947NL-F	
994/996L-M 994/996 L-M-BE Trim	9875L, 9975L, 9875L-F, 9975L-F	20006
E996L-M E996L-M-BE M996L-M M996L-M-BE Trim	9875L, 9975L, 9875L-F, 9975L-F	20006
994/996 L-DT Trim	98DT, 99DT, 98DT-F, 99DT-F	20004
	9827DT, 9927DT, 9827DT-F, 9927DT-F	
	9847DT, 9947DT, 9847DT-F, 9947DT-F	
	9875DT, 9975DT, 9875DT-F, 9975DT-F	
	9849DT, 9949DT, 9849DT-F, 9949DT-F	
994/996 L-R/V & 994/996 L-R/V-BE Trim	98L, 99L, 98L-F, 99L-F	20003
	9827L, 9927L, 9827L-F, 9927L-F	
	9847L, 9947L, 9847L-F, 9947L-F	
	9849L, 9949L, 9849L-F, 9949L-F	

98/99 Trims		
Trim	Used with	Template
E996L-R/V E996L-R/V-BE M996L-R/V M996L-R/V-BE Trim	98L, 99L, 98L-F, 99L-F,	20003
	9827L, 9927L, 9827L-F, 9927L-F,	
	9847L, 9947L, 9847L-F, 9947L-F	
	9849L, 9949L, 9849L-F, 9949L-F	
994/996 L-NL Rigid Trim	98NL, 99NL, 98NL-F, 99NL-F	20005
	9827NL, 9927NL, 9827NL-F, 9927NL-F	
	9847NL, 9947NL, 9847NL-F, 9947NL-F	
	9849NL, 9949NL, 9849NL-F, 9949NL-F	
	9875NL, 9975NL, 9875NL-F, 9975NL-F	

98/99 Series Controls		
Control	Used with	Template
374T Control	9827TL, 9927TL, 9827TL-F, 9927TL-F	40118
374T-BE Control	9827TL, 9927TL, 9827TL-F, 9927TL-F	40119
376T Control	9847TL, 9947TL, 9847TL-F, 9947TL-F	40114
376T-BE Control	9847TL, 9947TL, 9847TL-F, 9947TL-F	40115

98/99 Series Strikes		
Strike	Used with	Template
260U Strike	9827, 9927, 9827-F, 9927-F	30007
264 Strike	98 Rim, 99 Rim, 98-F Rim, 99-F Rim	30009
	9827, 9927, 9827-F, 9927-F	
299 Strike	98 Rim, 99 Rim	30039
	9827, 9927 9857, 9957	
299F Strike	98-F Rim, 99-F Rim	30039
	9827-F, 9927-F 9857-F, 9957-F	

98/99 Series Strikes		
Strike	Used with	Template
338 Strike	9847, 9947, 9847-F, 9947-F	30038
385A Strike	9847, 9947, 9847-F, 9947-F 9848, 9948, 9848-F, 9948-F	941371
499F	98/99-F Rim (pairs w/ mullion), 98/9927-F LBR	30040
575 Strike	9875, 9975, 9875-F, 9975-F	30210
575-2 Strike	9875, 9975, 9875-F, 9975-F	30212
576 Strike	9875, 9975, 9875-F, 9975-F	30211
1409 Strike	98 Rim, 99 Rim, 98-F Rim, 99-F Rim	30022
1410 Strike	98 Rim, 99 Rim	30023
1439 Strike	98 Rim, 98 Rim	30029
1606 Strike	98 Rim, 99 Rim, 98-F Rim, 99-F Rim	30024
1609 Strike	98 Rim x 9827, 98 Rim x 9827-F	30229
	99 Rim x 9927, 99 Rim x 9927-F	

330/350 Push Bar	
Device	Template
330 & 350 Push Bar	20030