



INSTALLATION INSTRUCTIONS

1. PREPARE INSIDE FACE OF DOOR FOR DEVICE.
 - A. SEE DEVICE DIRECTIONS FOR LOCATIONS OF VERT. AND DEVICE REF. CENTERLINES.
2. PREPARE OUTSIDE FACE OF DOOR FOR TRIM.
 - A. TRANSFER VERT. AND DEVICE REF. CENTERLINES FROM INSIDE FACE TO OUTSIDE FACE OF DOOR. BE SURE VERT. CENTERLINE IS PARALLEL TO EDGE OF DOOR.
 - B. LOCATE AND PREPARE ALL HOLES AS INDICATED.
3. INSTALL TRIM ON DOOR AND CUT THUMBPIECE TO SIZE.
 - A. TRIM MOUNTING.
 - BOTTOM STUD: 1/4"-20x3/4" FPHMS FINISH WASHER
 - TOP FOUR STUDS: ARE THRU-BOLTED TO DEVICE WHEN DEVICE IS INSTALLED.
 - NOTE: FOR F-18-R & F-XX-R DEVICES, INSERT SEXBOLTS INTO TWO HOLES PRIOR TO INSTALLING TRIM.
 - B. CUT THUMBPIECE.
 - RIM & VERTICAL: THUMBPIECE TO EXTEND 5/8"-3/4" BEYOND DOOR SKIN.
 - MORTISE: THUMBPIECE TO BE INSIDE DOOR SKIN BY 1/4".
4. ASSEMBLE CYLINDER (IF REQUIRED).
 - A. IF USING MORTISE CYLINDER, INSTALL CYLINDER TO MORTISE LOCK.
 - B. IF USING RIM CYLINDER, CUT TAILPIECE TO EXTEND 3/8" BEYOND INSIDE FACE OF DOOR.
5. INSTALL DEVICE ON DOOR PER DEVICE INSTRUCTIONS.

DEVICE	"A"	"B"	DEVICE	"A"	"B"
(F)XX-R-TP	OMIT	1-1/4"	(F)18-R-TP (BE)	OMIT	OMIT
(F)XX-R-TP (BE)	OMIT	OMIT	(F)18-R-TP (NL)	OMIT	1-1/4"
(F)XX-R-TP (NL)	OMIT	1-1/4"	(F)18-R-TP2	1-1/4"	OMIT
(F)XX-R-TP2	1-1/4"	OMIT	(F)18-R-TP (2O.C.)	1-1/4"	1-1/4"
(F)XX-R-TP (2O.C.)	1-1/4"	1-1/4"	(F)18-M-TP	1-1/4"	OMIT
(F)XX-M-TP	1-1/4"	OMIT	(F)18-M-TP (BE)	OMIT	OMIT
(F)XX-M-TP (BE)	OMIT	OMIT	(F)18-M-TP (NL)	1-1/4"	OMIT
(F)XX-M-TP (NL)	1-1/4"	OMIT	(F)18-M-TP2	1-1/4"	OMIT
(F)XX-M-TP2	1-1/4"	OMIT	(F)18-V-TP	1-1/4"	OMIT
(F)XX-V-TP	1-1/4"	OMIT	(F)18-V-TP (BE)	OMIT	OMIT
(F)XX-V-TP (BE)	OMIT	OMIT	(F)18-V-TP (NL)	1-1/4"	OMIT
(F)XX-V-TP (NL)		1-1/4"	OMIT (F)18-V-TP2	OMIT	1-1/4"
(F)18-R-TP	OMIT	1-1/4"	(F)18-V-TP (2O.C.)	1-1/4"	1-1/4"

FALCON[®]

TITLE:

APOLLO TRIM - TP FUNCTIONS FOR (F)18 & (F)XX SERIES DEVICES



D-2051