



Center Case Retrofit

XP98/XP99

VON DUPRIN.

Installation Instructions








Customer Service	
1-877-671-7011	www.allegion.com/us

© Allegion 2014 Printed in U.S.A. 911001-00 Rev. 01/14-b



Remove existing exit device and strike from door.

Note: Disconnect device wiring if necessary.



CAUTION

Old 299/299F or 499F strike cannot be used with XP98/99 device. Strike must be removed and replaced with new strike.

Old strike	Replace with
299/299F	909
499F	954



Match master cam function for new XP center case to that of removed center case.


Inspect underside of old center case for master cam.

If NL drive screw (shown below) has been removed, it must be removed from new XP center case as well.


If NL drive screw is present in old center case, leave NL drive screw in new XP center case.

Additionally, if NL drive screw is present in old centercase, handing of the lock slide must also be matched on the new XP center case.

To change handing of lock slide temporarily remove NL drive screw and rotate master cam until lock slide is in the same position as old center case (full up or full down).








6 Drill and tap two new support holes in door.


- A. Align plastic template with existing holes as shown.
- B. Mark 2 new holes as shown.
- C. Prepare 2 new holes per chart below:




NOTE:


If plastic template will not align correctly with the 4 outer holes, bolt new center case on door with the 4 screws and use it as a template to mark the 2 holes shown above.


Install 954 strike, if necessary.





Align strike along dashed centerline (Q) as shown.
This represents the centerline of the strike.
Prep two holes and install.






C. Attach strike with two

screws through slots.

– 954 Strike



Attach new XP center case to device as shown.




New retaining ring and pin must be installed securely. If pin comes out, door will not open properly.




Remove old center case.

- A. Remove old center case bracket.
- B. Slide mechanism case back approximately 5".



C. Remove retaining ring and pin, and two screws to remove old center case.



8

If device does not have plastic guide near center case, install plastic guide.

- A. Slide mechanism case off baseplate assembly.
- B. Lift push bar off baseplate assembly.
- C. Install new plastic guide on push bar near center case.
- D. Hold both plastic guides on push bar and reinstall push bar.
- E. Slide mechanism case back onto baseplate assembly.
- F. Verify that plastic guides stay on each end of pushbar.

