



24807570

CVC Cable Attachment

VON DUPRIN®


Installation Instructions

FOR DEVICES SOLD PRIOR TO 8-10-16


98/9949, 33/3549A

1 Install Cable(s).


a. Position red cable end to clip on center slide




b. Pull cable into clip to snap it into place



c. Push cable snap against center slide to secure cable




d. In the same way, install opposite end of red cable to top latch in the position marked red




For 2-Point Latch Only

e. There is an adjuster on one end of the white cable. Install this end to the remaining top latch position (marked as white)





f. Install opposite end of white cable to bottom latch



2 Refer to Device Instructions to Complete Installation.

CABLE REMOVAL

A cable removal tool was included with device. Slot in tool fits over cable, holding tabs down. Pull on cable snap to loosen cable for removal.




Cable A = Top Cable
Cable B = Upper Bottom Cable
Cable C = Lower Bottom Cable

1 Install Top Latch Cable Assembly.

a. Using **Cable A**, position cable end to clip on center slide, and snap it into place




b. Push cable snap against center slide to secure cable




c. Position opposite end of **Cable A** to the top latch in the position marked red. Pull cable into clip to snap it into place.

d. Push cable snap against latch to secure cable




For 2-Point Latch Only


e. Snap cable link onto one end of **Cable B**



f. Install **Cable B** to the top mounting bracket




g. Install opposite end of **Cable B** to the remaining top latch position (marked as white)




2 Install Bottom Latch Cable Assembly. For 2-Point Latch Only


One end of **Cable C** has an adjuster. Install this end to the bottom latch.




3 Temporarily Attach Bottom Latch Cable Assembly to Center Slide. For 2-Point Latch Only



Position **Cable C** to bottom mounting bracket on center slide



Push cable snap against mounting bracket to secure cable



Pull on cable end to attach it to the cable link

4 Refer to Device Instructions to Complete Installation.

CABLE REMOVAL

A cable removal tool was included with device. Slot in tool fits over cable, holding tabs down. Pull on cable snap to loosen cable for removal.

