


4270107667

## 1498 Inactive Device


Installation Instructions

## Prepare door and Install device.

- Prepare door as shown in Figure 1 below.
- 2. Cut pushbar as shown on reverse side of sheet.
- 3. Install mounting plate loosely on hinge stile (knobs facing stile) with #12-24 screws (See Figure 2 below). Do not fully tighten until final adjustments are made.
- Slide pushbar assembly into mounting plate on hinge stile. 4.



- 6. Install channel end caps on both ends (knobs of mounting plates fit into channel end caps). Tighten #12-24 screws.
- 7. Install pushbar end caps.





**Customer Service** 

1-877-671-7011 www.allegion.com/us

© Allegion 2014 Printed in U.S.A. 4270107667 Rev. 10/14-d

Figure 1

## Cut pushbar to length.

- 1. Measure Q to Q of mounting holes ("A" dimension Figure 3).
- 2. Subtract 1/2" from "A" dimension to determine cut length ("B" dimension in Figure 3 and 4). See chart below for minimum "B" dimension.

| Device     | "B" Dimension | Minimum "B" |
|------------|---------------|-------------|
| Length     | Supplied      | Dimension   |
| 36" device | 32-5/8"       | 21"         |
| 42" device | 38-5/8"       | 21"         |
| 48" device | 44-5/8"       | 30"         |

- 3. Tape around channel and pushbar in cutoff area, and mark "B" dimension on tape (see Figure 4).
- 4. Keep chips out of mechanism by stuffing a rag into end of pushbar before cutting. Keep rag out of the path of the saw. Cut pushbar and channel, deburr, and clean chips from pushbar and channel.
- **5.** Pull the two rubber bumper strips from the screw grooves, cut off 1" so the bumper strips are 1" shorter than the pushbar, and reinstall bumper strips into screw grooves.
- **6.** Tap #8-32 x 1" deep into each screw groove in end of pushbar.
- **7.** See reverse side for installation.




Figure 3




Figure 4